



# Dell Optiplex GX620 Fan Replacement

Written By: Padraic Hoselton





## TOOLS:

- [Phillips #2 Screwdriver](#) (1)
- [Spudger](#) (1)




## PARTS:

- [120mm fan](#) (1)






## Step 1 — Open up your PC.



- Insert wisdom here.




## Step 2 — Unplug your Hard drive.



- Unplug your hard drives power and data cables.





### Step 3 — Unplug floppy drive.



- Unplug the power and data cables.


### Step 4 — Unplug the fan.



- Unplug the fan.





## Step 5



- Remove the two Phillips #2 screws.


## Step 6 — Remove the heat sink.



- Pull the heat sink up.



## Step 7



- Pull the two tabs and pull it out.
- ⓘ This needs a lot of force to take it off.

## Step 8 — Take the fan out of its enclosure.



- To take the fan out you have to pull the two tabs and pull the fan out.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-11-28 12:51:37 AM.